

# Contents

<b>1</b>	<b>Introduction to Shock Wave Physics of Condensed Matter . . . . .</b>	<b>1</b>
1.1	Introduction . . . . .	1
1.2	General Assumptions . . . . .	1
1.3	Brief History of Shock Field in the United States of America . . .	2
1.4	Practical Value of Shock Field . . . . .	3
1.5	Techniques for Producing 1-D Plane Shock Waves . . . . .	4
1.6	Dynamic Versus Static Compression . . . . .	5
1.7	Select Areas of Shock Wave Research . . . . .	5
1.8	What Does a Shock Wave in Condensed Matter Look Like? . . . .	6
	References . . . . .	8
<b>2</b>	<b>Plane One-Dimensional Shock Waves . . . . .</b>	<b>13</b>
2.1	Definition of a Plane One-Dimensional Shock Wave . . . . .	13
2.1.1	A More Practical Definition for a Steady Shock Wave . . .	13
2.2	Practical Description of $U_s$ , $u_p$ , $E$ , $P$ and Disturbance Velocity . . .	14
2.3	Conservation Equations for a 1-D Plane Steady Shock Wave . . .	16
2.4	A Single Shock Wave Defines Only One $(P, v)$ Point on a Hugoniot . . . . .	18
2.5	Two Plane Shock Waves 1-D Conservation Relations . . . . .	20
2.6	Wave Stability . . . . .	21
2.6.1	Necessary Condition for a Shock Wave to Form . . . . .	22
	References . . . . .	29
<b>3</b>	<b>Impedance Matching Technique . . . . .</b>	<b>31</b>
3.1	Waves Response to Material Interfaces and Intersection with Other Waves . . . . .	31
3.1.1	Practical Uses for Impedance Matching . . . . .	31
3.2	Distance-Time $(x-t)$ Wave Propagation Diagrams . . . . .	31
3.3	Introduction to Principal $P-u$ Curves with Initial State $(P = 0, u = 0)$ . . . . .	33
3.4	Introduction to $P-u$ Curve with Initial State $(P_1, u_1)$ . . . . .	34
3.5	$P-u$ Curves for Materials with $U_s = A + bu_p$ . . . . .	36

3.6	P-u Diagram for a Shock Crossing a Boundary into a Material of Higher Impedance . . . . .	37
3.7	Impedance Matching Treatment of Rarefaction Waves . . . . .	38
3.8	Impedance Matching for a Shock Reaching a Free Surface . . . . .	39
3.9	Impedance Matching for a Flyer Plate Hitting a Stationary Plate of the Same Material . . . . .	41
3.10	Disturbance Velocity in a 1-D Eulerian Cartesian Coordinate System Fixed in Space . . . . .	42
	3.10.1 Symmetric Impact Example . . . . .	42
	3.10.2 Disturbance Velocity for General Case . . . . .	44
3.11	Impedance Matching for Four Basic Cases . . . . .	45
3.12	Impedance Matching for Thin Foils . . . . .	48
	3.12.1 Summary of the Practical Lessons for Thin Foils . . . . .	49
3.13	Impedance Matching for Multiple Waves Is an Approximation . . . . .	52
3.14	Wave-Wave Interaction and Contact Discontinuity . . . . .	53
	References . . . . .	57
<b>4</b>	<b>Experimental Techniques . . . . .</b>	<b>59</b>
4.1	Selected Experimental Techniques to Measure Shock Wave Parameters . . . . .	59
4.2	Explosive and Flyer Plate Shock Driver Systems . . . . .	59
4.3	Laser Shock Drivers . . . . .	62
4.4	Early Impedance Matching Experiments . . . . .	63
4.5	Shock Velocity Measurements . . . . .	64
4.6	Free Surface Velocity Measurement Using a Streak Camera . . . . .	66
4.7	Electromagnetic Particle Velocity Gauge . . . . .	67
4.8	Laser Velocity Interferometry . . . . .	68
4.9	VISAR . . . . .	68
4.10	ORVIS . . . . .	69
4.11	Fabry-Perot . . . . .	70
4.12	Heterodyne System . . . . .	71
4.13	Optical Windows on Test Samples . . . . .	72
4.14	Quartz Stress Gauge . . . . .	72
4.15	Quartz Gauge Technique for Measuring Low Pressure Hugoniot . . . . .	74
4.16	Quartz Gauge Technique for Measuring the Hugoniot of a Thin Material . . . . .	75
4.17	Manganin Stress Gauge . . . . .	75
4.18	Other Stress Gauges . . . . .	78
4.19	Proton Radiography for Accurate Density Measurements of Shock Wave . . . . .	80
4.20	Issues for Making Temperature Measurements Behind Shock Waves . . . . .	80
4.21	Error Analysis for Experiments . . . . .	82
4.22	Random Errors . . . . .	83

4.23	Systematic Errors . . . . .	85
4.24	Combining Random and Systematic Errors to Get Final Error . . . . .	86
4.25	Example of Errors in Measurement of a Cylinders Density . . . . .	86
4.26	Error Analysis for a Rotating Mirror Streak Camera	
	Measurement of Free Surface Velocity . . . . .	88
	4.26.1 Sources of Various Errors . . . . .	89
	4.26.2 Errors in Trace Angle $\gamma$ and Wave Tilt Angle $\omega$ . . . . .	90
	References . . . . .	94
<b>5</b>	<b>Thermodynamics of Shock Waves . . . . .</b>	<b>101</b>
5.1	Thermodynamics Review . . . . .	101
5.2	Fundamental Thermodynamic Relation . . . . .	102
5.3	Equations of State . . . . .	103
5.4	Hugoniot Is Steeper than Isentrope from Same Initial State . . . . .	105
5.5	Isentrope is Steeper than Isotherm from Same Initial State . . . . .	106
5.6	Entropy Along Hugoniot . . . . .	107
5.7	Isentrope and Hugoniot Are Same to Second Order in Compression at a Common (P, v) Point . . . . .	109
5.8	Differential Equation for Hugoniot . . . . .	110
5.9	Temperature at an Isentrope Point with $C_v\gamma/v$ Constant . . . . .	111
5.10	Temperature at a Hugoniot Point for $C_v\gamma/v$ Constant . . . . .	112
5.11	Calculation of Gruneisen Parameter at (P = 0, v <sub>0</sub> ) from Thermodynamic Parameters and Sound Speed Values . . . . .	114
5.12	Determination of Gruneisen Parameter from Shock Wave Release Velocity Measured at Peak Shock Pressure . . . . .	115
5.13	Numerical Calculations of Isentropes and Isotherms from Hugoniot Data for $C_v$ and $\gamma/v$ Assumed Constant . . . . .	116
5.14	Thermodynamic Consistent Surface . . . . .	118
5.15	Complete Consistent Equation of State for Materials with a Constant $C_v$ . . . . .	120
5.16	Thermodynamic Surface Defined by Isotherm with a Constant $C_v$ . . . . .	122
5.17	Isentrope and Isotherm on the Thermodynamic Surface with $C_v$ and $\gamma/v$ Constant and Principal Hugoniot as the Reference Curve . . . . .	130
5.18	Mie-Gruneisen Equation of State . . . . .	133
5.19	Mie-Gruneisen Equation of State with $C_v\gamma/v$ Constant and Principal Hugoniot as the Reference Curve . . . . .	134
5.20	Thermodynamics Impose Stringent Constraints on Use of the Gruneisen Equation of State With Hugoniot as Thermodynamic Reference Curve . . . . .	135
5.21	Calculation of Hugoniot Where Initial Temperature Is Different than Principal Hugoniot's with $C_v$ and $\gamma/v$ Assumed Constant . . . . .	136
5.22	Recentered Hugoniot Using Gruneisen Equation of State with $C_v$ and $\gamma/v$ Constant . . . . .	137
5.23	Determination of Volume Dependence of $\partial P/\partial T$ <sub>V</sub> or $\gamma(v)$ . . . . .	139
	References . . . . .	144

<b>6 Solids</b> . . . . .	147
6.1 Compression of Solids . . . . .	147
6.2 Hookes Tensor Law for Elastic Isotropic Solids . . . . .	149
6.3 Uniaxial Stress . . . . .	149
6.4 Hydrostatic Pressure on a Solid . . . . .	151
6.5 Uniaxial Strain . . . . .	151
6.6 Elastic–Plastic Solids Under 1-D Plane Shock Loading . . . . .	152
6.7 Elastic–Plastic 1-D Plane Shock Compression Treatment Using Hooks Law for Isotropic Solids . . . . .	153
6.8 Impedance Matching Issues for Elastic–Plastic Material with a Free Surface . . . . .	157
6.9 Material Strength at High Stress Hugoniot States . . . . .	163
6.10 Porous Materials . . . . .	164
6.11 Simple Model for Totally Compacted Porous Material When Strength Can Be Ignored . . . . .	166
6.12 Gruneisen EOS for Porous Material with Principal Hugoniot as Reference and $\gamma/v$ Constant . . . . .	167
6.13 Temperature for a Shocked Porous Material with $C_v$ Constant and Pores Are Totally Compacted with Strength Ignored . . . . .	168
6.14 Phenomenological P- $\alpha$ Model for Porous Material Not Totally Compacted . . . . .	170
6.15 Snowplow Model for Shock Wave Attenuation in Porous Solids . . . . .	173
References . . . . .	177
<b>7 Differential Conservation Equations and Time-Dependent Flow</b> . . . . .	179
7.1 Mass, Momentum and Internal Energy Fluxes for 1-D Flow . . . . .	179
7.2 Mass Differential Conservation Equation . . . . .	180
7.3 Momentum Differential Conservation Equation . . . . .	182
7.4 Rayleigh Line Is Compression Path for a Steady Shock Wave . . . . .	183
7.5 Energy Differential Conservation Equation . . . . .	184
7.6 Summary of Eulerian Differential Conservation Equations . . . . .	186
7.7 Rise-Time and Shape of a Steady Shock Wave Due to Viscosity . . . . .	186
7.8 Visco-Elastic Properties Represent Behavior of Polymethylmethacrylate (PMMA) Under Shock Loading . . . . .	189
7.9 Time-Dependent Material Properties Overview . . . . .	192
7.9.1 Elastic–Plastic Solids . . . . .	192
7.9.2 Elastic–Plastic Solid that Undergoes a Phase Transition . . . . .	193
7.9.3 Initiating High Explosive . . . . .	195
7.10 Time and Spatial Scales Affect Dynamic Material Response . . . . .	196
7.11 Elastic Wave Stress Decay Described by a Maxwell-Like Material Model . . . . .	197
References . . . . .	199

**8 First-Order Polymorphic and Melting Phase Transitions Under Shock Loading** . . . . . 201

8.1 Introduction . . . . . 201

8.2 General Background of Polymorphism Under Shock Compression . . . . . 203

8.3 Select Observed Transitions in Shocked Materials . . . . . 203

8.4 Fast Reversible Phase Transition in Iron . . . . . 206

8.4.1 Evidence for Non-equilibrium Behavior in Mixed Phase Region of Iron . . . . . 208

8.4.2 Martensitic Phase Transition . . . . . 209

8.5 Steady Shock Wave Profiles for Shock Compressed Thick Iron Samples . . . . . 210

8.6 Experimental Rise-Time Measurements of the Steady Plastic II Shock in Polycrystalline Iron . . . . . 212

8.7 Permanent Regime Theory for Rise-Time of a Steady Transmitted Shock Wave Front Where the Phase Transition Occurs and Material Strength Is Ignored . . . . . 213

8.8 Time-Dependent Flow for Transmission Shock Waves in Iron for Thin Samples . . . . . 217

8.9 Kinetics of Plastic I Shock Decay . . . . . 222

8.10 Reverse Impact Experiments of Iron onto a VISAR Window . . . . . 225

8.11 Fast Shock Induced Phase Transition in KCL with Two Measured Rates from Reverse Impact Experiments . . . . . 226

8.12 Polymorphic Phase Transitions with Slow Transition Rates . . . . . 228

8.13 Nucleation of Phase Transitions Under Shock Loading . . . . . 229

8.14 Solid and Liquid Phase Thermodynamic Surface for Aluminum . . . . . 232

8.15 Melting in Shocked Porous Aluminum . . . . . 234

8.16 Shock Loading Porous Aluminum Along Metastable Extension of Solid Hugoniot Above the Solid Melt Line . . . . . 236

8.17 Determination if Fully Compacted Aluminum Can Melt Under Pressure Release Down an Isentrope After Being Shock Loaded . . . . . 237

References . . . . . 238

**9 Secondary Ideal High Explosives Non-steady Initiation Process and Steady Detonation Wave Models** . . . . . 243

9.1 Explosives . . . . . 243

9.2 Secondary Explosives Initiation . . . . . 245

9.3 High Pressure Shock Initiation of Homogeneous Explosives . . . . . 247

9.4 Low Pressure Shock Initiation of Heterogeneous Explosives . . . . . 247

9.5 High Pressure Shock Initiation of Heterogeneous Explosives . . . . . 250

9.6 Phenomenological Energy Fluence Initiation Model . . . . . 250

9.7 Phenomenological Reactive Flow Reaction Rate Models for Heterogeneous HE Initiation . . . . . 252

9.8 Shock Sensitivity Tests . . . . . 255

9.9	Steady 1-D Detonation Shock Waves in Near-Ideal Explosives . . . . .	259
9.10	Chapman-Jouget (CJ) Detonation Model for Near Ideal High Explosives . . . . .	261
9.10.1	Case 1 Initiation by Thick Driver Plate . . . . .	262
9.10.2	Case 2 Initiation by Very Thin Flyer or a Booster HE with Its Initial Surface Free . . . . .	262
9.11	CJ Detonation Model with Polytropic Equation of State for Gas Products . . . . .	264
9.12	Peak Pressure Induced in Material by Explosive Using CJ Detonation Model . . . . .	267
9.13	P-u Curves for Comp B Explosive Products Using Polytropic Gas Equation of State . . . . .	269
9.14	Explosive Product Curves from JWL Equation of State . . . . .	271
9.15	ZND Detonation Model . . . . .	274
9.16	Detonation Spike Pressure Estimates . . . . .	276
9.17	Pressure Drop Behind Detonation Spike . . . . .	277
9.18	Thermal Initiation of Explosives . . . . .	278
9.19	Adiabatic or Instantaneous Volume Thermal Explosion . . . . .	282
	References . . . . .	285
<b>10</b>	<b>Steady Detonation Waves in Right Circular Cylinders of Non-ideal Explosives . . . . .</b>	<b>291</b>
10.1	Non-ideal Explosives . . . . .	291
10.2	Non-ideal Explosive’s Evidence of Late-Time Energy Release . . . . .	294
10.3	Summary of Key Detonation Properties Due to Two Dimensional Flow in Right Circular Cylinders of Explosives . . . . .	296
10.4	Detonation Wave Velocity, Curvature and Failure Diameter Measurement Techniques . . . . .	297
10.5	Thin Foil Velocity Technique for Measuring CJ State of a Near-Ideal HE . . . . .	303
10.6	Navy Impedance Matching Technique for Measuring CJ State . . . . .	305
10.6.1	Simple Approximate Solution for Polytropic Parameter G from Navy Technique . . . . .	307
10.7	CJ States Defined by Determining JWL Equation of State for Near Ideal HE’s . . . . .	309
10.8	Orvis Line VISAR Technique with Very Good Temporal Resolution to Measure CJ Reaction Zone Length of a Near-Ideal HE . . . . .	310
10.9	1-D Experimental Technique for Determining Sonic Plane . . . . .	316
10.10	Significance of Experimental Measurements of Detonation Wave Properties . . . . .	317

10.11	Curved Front Detonations in Right Circular High Explosive Cylinders . . . . .	318
10.12	Calculated PBXN-111 Detonation Sonic Zone Lengths as a Function of Cylinder Diameter . . . . .	321
10.13	2D Flow Across Curved Shock Front . . . . .	323
	References . . . . .	326
<b>11</b>	<b>Special Topics: Lagrangian Coordinates, Spall, and Radiation</b>	
	<b>Induced Shocks</b> . . . . .	329
11.1	Lagrangian Coordinates . . . . .	329
11.2	Steady Flow of Two Forward Facing Shock Waves in Eulerian and Lagrangian Coordinates . . . . .	330
11.3	Conservation Equations for Two Steady Forward Facing Shocks in Lagrangian Coordinates . . . . .	333
11.4	Relief Wave Speeds . . . . .	334
11.5	Sound Speed Determined from Symmetric Impact . . . . .	335
11.6	Lagrangian Differential Conservation Equations . . . . .	337
11.7	Planar Spall of Materials Under Dynamic Loading . . . . .	338
11.8	Dynamic Method of Detecting Spalling . . . . .	341
11.9	Spall Strength of Condensed Matter . . . . .	343
11.10	Smooth Planar Spall Due to a Fast Reversible Phase Transition . . . . .	344
11.11	Radiation Induced Shocks . . . . .	346
	References . . . . .	352
	<b>Erratum to: Shock Wave Compression of Condensed Matter</b> . . . . .	E1
	<b>Appendix 1: Symbols, Useful Conversion Factors, and Some Basic Equations for Steady Shock Waves</b> . . . . .	355
	<b>Appendix 2: Hugoniot for Some Materials</b> . . . . .	359
	<b>Appendix 3: One-Dimensional Steady Shock Conservation Equations</b> . . . . .	361
	<b>Appendix 4: Impedance Matching Rule and Four Basic Examples</b> . . . . .	363
	<b>Appendix 5: Analytical Impedance Matching for Two Most Common Cases</b> . . . . .	365
	<b>Appendix 6: Thermodynamic Parameter Definitions and Relationships</b> . . . . .	367
	<b>Index</b> . . . . .	371