# EARLINET APPROACH TO OPTIMISATION OF INDIVIDUAL NETWORK INSTRUMENTS WITH THE AIM OF HOMOGENISATION OF AEROSOL DATA PRODUCTS AND INCREASED DATA COVERAGE

Arnoud Apituley\* (RIVM, Bilthoven, The Netherlands)

Volker Freudenthaler (University of Munich, Germany)

Adolfo Comerón, Francesc Rocadenbosch (Universitat Politècnica de Catalunya (UPC, Barcelona, Spain)

### **ABSTRACT**

The European Aerosol Research LIdar NETwork (EARLINET) is an aerosol lidar network on a continental scale. EARLINET is now a leading network in qualitycontrolled quantitative aerosol profiling performing a schedule of routine measurements and presently consists of 28 stations distributed over Europe. The construction of an un-biased spatio-temporal database of vertical profiles of aerosol optical properties on a regional scale for climate and air quality research is the main objective of EARLINET and is accomplished through application of Raman lidars. One of the tasks in the EC-funded project EARLINET-ASOS is to optimize individual instruments with the aim of homogenization of aerosol data products over the network and increased data coverage by automation. This task is approached by selection of optimal solutions existing in the pool of individual stations. This is done for components, subsystems as well as for system integration. In system integration emphasis lies on automation to reduce the amount of manpower needed, to improve temporal coverage, and to make performance independent from individual operators. The procedure to perform these tasks is outlined and the set of tools enabling the assessment of performance under development is described.

*Index Terms*— Lidar, network, aerosol, harmonization, automation

### 1. INTRODUCTION

Among the factors causing the largest uncertainties in the understanding of climatic change are aerosols and cloud feedback mechanisms involving the role of aerosols. This is due to the variable nature in space and time of the aerosols, that are relatively short-lived atmospheric species, but can still be distributed over large distances when the conditions are right. Aerosols and their climatic impact are therefore much more difficult to catch in atmospheric models than long-lived greenhouse gases such as carbondioxide. Better

knowledge of the spatio-temporal distrubution of aerosols is critically needed to better assess their role in climate change [1].

The European Aerosol Research LIdar NETwork (EARLINET) started in 2000 under the EC 5th Framework Program. The network presently consists of 28 stations distributed over Europe (from Norway to Spain and from Ireland to Georgia). The construction of an un-biased spatiotemporal database of vertical profiles of aerosol optical properties on a regional scale for climate and air quality research is the main objective of EARLINET. This cannot be accomplished by backscatter lidars since these do not provide quantitative optical aerosol data without critical assumptions. Therefore, EARLINET aims to apply mainly Raman lidars that *are* quantitative.

The increasing number of participating stations illustrate the success of this initiative. However, in order to build the aerosol database, rigorous quality assurance is needed and also homogeneous data quality is desired so that the network can be used truly as a single instrument. Most stations in the network have lidars that were not series-produced and consequently these instruments have differences in set-up and construction. Consequently, the performance of the individual instruments may be different, for instance with respect to the altitude range covered or the number of operating wavelengths.

From 2006 until 2011, the network's development is supported by the EC-project EARLINET- ASOS (Advanced Sustainable Observation System). The main objective of this Coordination Action is to improve the EARLINET infrastructure for better spatial and temporal coverage of the observations, continuous quality control for the complete observation system, and fast delivery of standardized data products. One of the tasks in EARLINET-ASOS is to optimize individual instruments with the aim of homogenization of aerosol data products over the network and increased data coverage by automation.

This will be accomplished by selecting the optimal approach from the various solutions existing at individual stations for components and subsystems as well as for system


<sup>\*</sup> RIVM – National Institute for Public Health and the Environment, P.O. Box 1, NL3720BA Bilthoven, The Netherlands. Email: Arnoud.Apituley@rivm.nl.

integration. In system integration emphasis is on automation of operation to reduce the amount of manpower needed, to improve temporal coverage, and to make performance independent from individual operators.

### 2. HANDBOOK OF INSTRUMENTS

The EARLINET approach for optimization and harmonization of the instrument performance across the network is starts with an extensive list of system parameters that all stations' instrument PI's are required to complete: the Handbook of Instruments (HoI). The basis of the structure of the HoI is a generic lidar system, such as depicted in Fig.1. The HoI's structure can accommodate a wide variety of system configurations that can still be evaluated using exactly the same tools. The HoI allows for multiple emitted wavelengths, from one or more lasers. The detection chain is set up for each detected wavelength separately and includes parameters to adequately describe the properties of the detection channels in terms of e.g. spectral response, detector efficiency, polarisation properties, etc. The total number of parameters for a single wavelength backscatter lidar is about 100. Station characteristics, including accessibility of ancillary data such as radiosondes and sunphotemeters are also included.

In this way the HoI thoroughly documents each EARLINET station and serves as an inventory of existing technical solutions in the network for quantitative aerosol profiling and as a characterization of the station.



**Fig.1.** Generic set-up of a lidar system with a laser emitter, a receiving telescope, wavelength-selection, a light sensitive detector and recording electronics.

The HoI will be used in the following way:

Assess conceptual performance and performance limits
of lidar systems by using the configuration data provided to model (parts of) individual systems. This can
be done, for instance, for an isolated detection channel
(i.e. one detected wavelength) in a particular lidar. In
this way, it becomes possible to compare lidar systems'

- characteristics among each other and reduce the necessity for direct instrument intercomparisons.
- The handbook provides a detailed overview of possible configurations of lidars for aerosol profiling that will be studied to find optimized solutions. This is particularly helpful to new groups that will be able to benefit from existing knowledge.
- The handbook will be studied to find the more common problems where joint efforts are expected to yield effective results on the improvement on the over-all quality of the data provided by the network.

The HoI is set up as 'live' documentation on the web and is accessible through the internal EARLINET web-pages. Since it is expected that the instruments in the network to be improved upon during the course of the project, all groups are requested to update the information on their configuration changes as soon as it is used for production of data submitted to the database. Older configurations, used for data production in the past, can still be retrieved after newer configurations have taken effect.

## 3. INSTRUMENT OPTIMIZATION AND HARMONIZATION

Optimization and harmonization of the instrument performance given the wide variety of instruments in the network is a task not to be underestimated. The number of instrumental details to be addressed can become very large, considering the wide variety of issues and lidar systems involved. Therefore, the activity started looking for optimizations fitting the following overall goals:


- Optimal performance for the main data products of our lidars for aerosol pro-filing: i.e. aerosol backscatter profiles, aerosol extinction profiles and lidar ratio. The minimum recommendation for an optimized product is to add a nitrogen Raman channel to a backscatter lidar.
- Daytime performance.
  - Aerosol radiative properties play their most important role during daytime. Aerosol characteristics can change in relatively short periods of time. The lidar ratio obtained during nighttime measurements can differ significantly from that actually occurring in aerosols whose elastic backscatter is measured during daytime hours before or after. Therefore daytime measurements of the aerosol properties are needed and technical solution to accomplish this.
- Increased operationality
  Increase automation in instrument control so that more
  data will become available, at a reduced manpower/data
  ratio. This will be treated separately.

The overall optimization and harmonization requires 1) a set of tools that are used to evaluate actual system performance based on the data provided in the HoI, and 2) a set of requirements for the EARLINET database and 3) a set of hardware tests to diagnose instrumental problems. Where

discrepancies between 1) and 2) exist, further tests with 3) may be used to indicate malfunctioning or badly configured hardware. Sub-optimal configurations can be identified.

The general approach can be broken down in the following iterative sequence:

- 1. Collect essential system information and compile it in the handbook of in-struments (HoI)
- Define criteria for system performance, according to requirements of the EARLINET database (i.e. maximum error of aerosol properties vs height. These requirements will be classified in a number of categories. Suggested are PBL, PBL+ residual layers, Upper free troposphere)
- 3. Develop and apply tools to assess individual system performance, based on data in the HoI, and perhaps system intercomparisons
- 4. Check the system performance against the requirements in 2
- If errors are found to be outside the requirements, optimizations are needed
- 6. HoI can be used to find improvements and implement them. Perhaps new technologies need to be developed.
- 7. Update HoI
- 8. Re-iterate from 4



**Fig.2** Graph schematically indicating system performance. Each colored circle represents a lidar system, that may appear in more than one category (e.g. PBL range coverage, free tropospheric range coverage, high performance multiwavelength system). After optimization, all systems should migrate into the acceptable region to the left.

Specific tools that are used to assess system performance can be split between tools dealing with the optical configuration of the system and tools dealing with the electrical sub-systems and data acquisition electronics.

For the optical part, ray-tracing techniques can be applied to test theoretical performance against practice. Experimental tests have also been developed to look at the properties of optical sub-systems. For instance, when the different parts of the collecting area of the receiving telescope are covered during test measurements, intricately hidden problems in the receiver may be revealed [2].

From the point of view of the signal processing, tools are currently underdevelopment that convert the data in the HoI into dimensionless parameters that can be used to assess performance limits on a per-channel basis, beyond the simple power-aperture product. [3]

Recently, inversion algorithms have been developed to obtain microphysical aerosol properties such as effective radius, volume and surface-area concentration, real and imaginary part of the complex refractive index, and singlescattering albedo from multi-wavelength Raman lidar observations. Backscatter coefficients at three wavelengths (355, 532, 1064 nm) plus extinction coefficients at two wavelengths (355, 532 nm) are the minimum required input data for such inversion schemes [4]. Presently, eight EARLINET stations perform at this level. EARLINET strives to further increase the number of stations equipped with such high-performance instruments and the approach for optimization and tools presented here are expected to play an important part in this. If our approach is successful, also, future expansion of EARLINET data products can be instrumentally optimized in this way.

More and more frequently, new data products are requested from the network, such as cloud data. These new data products also require specific optimizations of the lidar systems. The optimization and harmonization activity in EARLINET-ASOS will play a role in this.

### 4. SYSTEM INTEGRATION

System integration is a separate subject, since it is not directly related to the scientific data products that are produced, but proper integration as well as automation, can have a tremendous impact on reliability and operability of an instrument. So proper integration is a prerequisite to steady and reliable dataflow and to make performance independent from individual operators.

To clarify what can be done at various levels of system integration and automation, the generic lidar is broken down in sub-systems. For each sub-system a range of possibilities is given for integration, taking into account mechanical, optical, electronic and remote control issues. An inventory of requirements and solutions are per sub-system is compiled in a structure starting from sub-systems to lager units:

- Integration, e.g.
  - o Mechanical stability
  - o Serviceable
  - o Modular
  - o Upgradable
  - Electrical noise control
- Automation of Sub-Systems, e.g.
  - Overlap control
  - Laser power stabilization
  - o Adjustable signal dynamic range
- Housing, e.g.
  - o Climatisation
  - Closed window

**Tab.1** Example of a Handbook of Instruments table for a Raman lidar with a three wavelength laser and three separate

receiving telescopes for close range, far range and polarisation measurements.

EARLINET Station																
Status updated Station	BH 2008 05 01	ringtituut voor 1/d	lkegozopskojd or	Million (DIVM)												
System name	Caeli	SINSTITUUT VOOR VO	nksidezonaniala ei	i Milleu (RIVM)	i	1			1	1			.!	i		
Home Location Home Location Coordinates	Bilthoven, NL 52.12 N	5.2 E	5 m asl		ļ	· <del></del>										
Home Location Environment	urban	4	ļ		\$	1	J			1		1				
System transportable Emitter	no Laser 1		i	-		1								-		
Laser type Laser manufacturer	Nd:YAG Continuum								<u> </u>	ļ		<u> </u>				
Laser model	PowerLite Precis	ion II 9030 SI				÷	†		<del>}</del>	†	ļ	÷	÷			
Seeder Seeder bandwidth	yes 0.003 cm^-1				ļ	Ţ	Ţ			Ţ		-	Ţ			
Seeder manufacturer	LightWave				Ż	3	·	<u> </u>	ł	1	<u> </u>	:::::::::::::::::::::::::::::::::::::::	:::::::::::::::::::::::::::::::::::::::			
Seeder model Pulse energy total (typ.)	Series 101 1.6 J				ļ	·{	+		}	· <del> </del>	<del> </del>	÷				
Repetition rate	30 Hz				÷	1	<u> </u>			1		<u> </u>	· <u></u>			
Wavelength Pulse energy (typ.)	1064 nm 0.45 J	532 nm 0.16 J	355 nm 0.36 J		+	-}	<del></del>		{	÷	ļ	<u> </u>	÷			
Pulse length (typ.)	9 ns	8 ns	7 ns		1		J					<u> </u>	÷	-4		
Polarization and purity (nominal) Polarisation purity measured	linear	linear >95%	linear >95%		÷	÷	÷		f	÷	ļ	<u> </u>	÷			
Polarisation orientation Laser beam diameter (mm)	horizontal 9 mm fwhm	vertical	horizontal		\$	1	.;			1			.;	;		
Laser beam diameter (mm) Laser beam divergence	0.5 mrad fw at 8	86% of energy			÷	-{	+	ļ	}		<del> </del>	· <del> </del>				
Beam expansion type	n.a.				Ţ	ļ	ļ			ļ	ļ	ļ				
Beam expansion factor Beam divergence					<del>†</del>	<del>}</del>	<del>†</del>		<del></del>	<del>†</del>	·	<del>†</del>	<del> </del>	+		
Alignment Alignment control	manual / automa gridscan at 1 km	atic overlap scan												7		
Alignment accuracy	0.125 mrad				<u> </u>	÷	T.			1	<u> </u>	÷	÷			
Receiver Optics Telescope type	Telescope 1	Telescope 1 (NFR) Newton							Telescope 2         (POL)         Telescope 3         (FFR)           Refracting         Newton							
Telescope manufacturer / model	Optical Surfaces							Newport Intermountain Optics								
Telescope aperture diameter Telescope obscuration diameter	0.15 m 0.05 m						0.463 m n.a.		0.575 m 0.05 m							
Focal length	0.42 m						0.1 m		1.72 m							
Field of view Fieldstop type	1.3 mrad fw Ontical fiber					1.3 mrad fw Pinhole		1.3 mrad fw Ootical fiber								
Fieldstop size	600 µm core diameter 0.22						150 µm diamete	µm diameter 1.8 mm core diameter								
Optical fiber Numerical Aperture Optical fiber manufacturer	Ceram Optech						n.a.		0.22 Ceram Ootech							
Optical fiber type Telescope-laser axes distance	single step, SMA2/UV600/660P-UVNS/BPVC-3.80mm/3.0M 170 / 138 / 171 mm															
Collimation system type / model	Singlet lens						Singlet lens	229 mm Singlet lens Singlet lens								
Collimation focal length Detection channels	100 mm						62.9 mm		100 mm							
Centre wavelength	1064 nm	387 nm	355 nm	607 nm	407 nm	532 nm	532 nm	532 nm	1064 nm	387 nm	355 nm	607 nm	407 nm	532 nm		
Scattering mechanism Wavelength separation Separation Passband bandwidth Separation transmission* Separation transmission pol. Parallel	Elastic DBS	vibr.Raman N2 DBS	Elastic DBS	vibr.Raman N2 DBS	vibr.Raman WV DBS	Elastic DBS	Elastic parallel n.a.	Elastic cross n.a.	Elastic DBS	vibr.Raman N2 DBS	Elastic DBS	vibr.Raman N2 DBS	vibr.Raman WV DBS	Elastic DBS		
Separation transmission pol. Cross																
Out of band suppression Passband bandwidth	IFF 10 nm fwhm	IFF 1 nm fwhm	IFF 3 nm fwhm	IFF 1 nm fwhm	IFF 1 nm fwhm	IFF 3 nm fwhm	IFF 3 nm fwhm	IFF 3 nm fwhm	IFF 3 nm fwhm	IFF 1 nm fwhm	IFF 3 nm fwhm	IFF 1 nm fwhm	IFF 1 nm fwhm	IFF 3 nm fwhm		
Passband transmission	0.8 > OD 4	0.75	0.55	0.7	0.8	0.7	0.7	0.7	0.8	0.8	0.55	0.8	0.8	0.7		
Out of band blocking Polarization separation		OD 8 nominel	>OD 5	OD 8 nominel	OD 8 nominel	> 0D 4	> OD 4 PCB	> OD 4	> OD 4	OD 8 nominel	>OD 5					
								PCB				OD 8 nominel	OD 8 nominel	> OD 4		
Pol. Transmission parallel Pol. Transmission cross	. 55 4						>0.95 <0.01	>0.99				OD 8 nominei	OD 8 nominel	> OD 4		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio		0.0 (variable)	3 (variable)	0.00	0.6 (variable)	1.7 (variable)	>0.95 <0.01 1.00E-03	>0.99	0.80	0.0 (variable)	3 (variable)					
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Detector type	0.80 APD	0.0 (variable) PMT	3 (variable) PMT	0.00 PMT	0.6 (variable) PMT	1.7 (variable) PMT	>0.95 <0.01 1.00E-03 1.0 (variable) PMT	>0.99 1.0 (variable) PMT	0.80 APD	PMT	3 (variable) PMT	0.00 PMT	0.6 (variable) PMT	1.7 (variable) PMT		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Detector type Detector manufacturer	0.80	PMT Hamamatsu	PMT Hamamatsu	PMT Hamamatsu	0.6 (variable) PMT Hamamatsu R7400-P03	PMT Hamamatsu	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu	>0.99  1.0 (variable) PMT Hamamatsu		0.0 (variable) PMT Hamamatsu R7400-P04	PMT Hamamatsu	0.00	0.6 (variable) PMT Hamamatsu	1.7 (variable) PMT Hamamatsu		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Detector type Detector manufacturer Detector model Additional features	0.80 APD Licel APD3	PMT Hamamatsu R7400-P04	PMT	PMT Hamamatsu R7400-P03	PMT Hamamatsu R7400-P03	PMT Hamamatsu R7400-P03	>0.95 <0.01 1.00E-03 1.0 (variable) PMT	>0.99 1.0 (variable) PMT Hamamatsu R7400-P03	APD Licel APD3	PMT Hamamatsu R7400-P04	PMT Hamamatsu R7400-P03	0.00 PMT Hamamatsu R7400-P03	0.6 (variable) PMT Hamamatsu R7400-P03	1.7 (variable) PMT Hamamatsu R7400-P03		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Detector type Detector manufacturer Detector model Additional features Daytime capability Data Acquisition	0.80 APD Licel APD3 yes	PMT Hamamatsu R7400-P04 no	PMT Hamamatsu R7400-P03 yes	PMT Hamamatsu R7400-P03	PMT Hamamatsu R7400-P03	PMT Hamamatsu R7400-P03 yes	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 yes	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03 yes	APD Licel APD3 yes	PMT Hamamatsu R7400-P04	PMT Hamamatsu R7400-P03 yes	0.00 PMT Hamamatsu R7400-P03	0.6 (variable) PMT Hamamatsu R7400-P03	1.7 (variable) PMT Hamamatsu R7400-P03 yes		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Detector type Detector manufacturer Detector manufacturer Detector model Additional features Daytime capability Data Acquisition Data acquisition mode	0.80 APD Licel APD3 yes Analoq	PMT Hamamatsu R7400-P04	PMT Hamamatsu	PMT Hamamatsu R7400-P03	PMT Hamamatsu R7400-P03	PMT Hamamatsu R7400-P03	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu	>0.99 1.0 (variable) PMT Hamamatsu R7400-P03	APD Licel APD3	PMT Hamamatsu R7400-P04	PMT Hamamatsu R7400-P03	0.00 PMT Hamamatsu R7400-P03	0.6 (variable) PMT Hamamatsu R7400-P03	1.7 (variable) PMT Hamamatsu R7400-P03		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Detector type Detector model Detector model Detector model Data Acquisition Data Acquisition mode Transmipedance Amplifier Transmipedance Gain	0.80 APD Licel APD3 yes Analog	PMT Hamamatsu R7400-P04 no Analog/PC	PMT Hamamatsu R7400-P03 yes Analog/PC	PMT Hamamatsu R7400-P03 no	PMT Hamamatsu R7400-P03 no	PMT Hamamatsu R7400-P03 yes Analog	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 yes	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03 yes PC	APD Licel APD3 yes	PMT Hamamatsu R7400-P04 no	PMT Hamamatsu R7400-P03 yes	0.00 PMT Hamamatsu R7400-P03 no	0.6 (variable) PMT Hamamatsu R7400-P03	1.7 (variable) PMT Hamamatsu R7400-P03 yes		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Detector type Detector model Additional features Daytime capability Data Acquisition Data acquisition Data acquisition	0.80 APD Licel APD3 yes Analog no	PMT Hamamatsu R7400-P04 no Analoq/PC no	PMT Hamamatsu R7400-P03 yes Analog/PC no	PMT Hamamatsu R7400-P03 no	PMT Hamamatsu R7400-P03 no	PMT Hamamatsu R7400-P03 yes Analoq no	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 yes	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03 yes PC	APD Licel APD3 yes Analoq no	PMT Hamamatsu R7400-P04 no	PMT Hamamatsu R7400-P03 yes	0.00 PMT Hamamatsu R7400-P03 no	0.6 (variable) PMT Hamamatsu R7400-P03	1.7 (variable) PMT Hamamatsu R7400-P03 yes		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio	0.80 APD Licel APD3 yes Analoq no 50 Ohm 40 MS/s	PMT Hamamatsu R7400-P04 no Analoq/PC no 50 Ohm 40 MS/s	PMT Hamamatsu R7400-P03 yes Analoq/PC no 50 Ohm 40 MS/s	PMT Hamamatsu R7400-P03 no PC no	PMT Hamamatsu R7400-P03 no PC no	PMT Hamamatsu R7400-P03 yes Analoq no 50 Ohm 40 MS/s	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 yes	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03 yes PC no	APD Licel APD3 yes Analoq no 50 Ohm 40 MS/s	PMT Hamamatsu R7400-P04 no PC	PMT Hamamatsu R7400-P03 yes PC no	0.00 PMT Hamamatsu R7400-P03 no	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no	1.7 (variable) PMT Hamamatsu R7400-P03 yes PC no		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Detector type Detector type Detector type Detector densification Detector densification Detector densification Detector densification Detector type Data Acquisition Data acquisition mode Transimpedance Ampillier Transimpedance Bandwidth Transimpedance Bandwidth Analog sampling rate Bandwidth Bandwidth	0.80 APD Licel APD3 yes Analoq no 50 Ohm 40 MS/s 30 MHz 12 bit	PMT Hamamatsu R7400-P04 no Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit	PMT Hamamatsu R7400-P03 yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit	PMT Hamamatsu R7400-P03 no PC no	PMT Hamamatsu R7400-P03 no PC no	PMT Hamamatsu R7400-P03 yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 yes	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03 yes PC no	APD Licel APD3 yes Analoq no 50 Ohm 40 MS/s 30 MHz 12 bit	PMT Hamamatsu R7400-P04 no PC	PMT Hamamatsu R7400-P03 yes PC no	0.00 PMT Hamamatsu R7400-P03 no	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no	1.7 (variable) PMT Hamamatsu R7400-P03 yes PC no		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter Ob Neutral density filter Ob Detector manufacture Detector manufacture Detector model Additional features Daytime capability Data Accidition Transmipedance Ampiller Transimpedance Ampiller Transimpedance Bandwidth Output impedance Analog sampling rate Bandwidth Input termination	0.80 APD Licel APD3 Yes Analoq no  50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm	PMT Hamamatsu R7400-P04 no Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm	PMT Hamamatsu R7400-P03 yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm	PMT Hamamatsu R7400-P03 no PC no	PMT Hamamatsu R7400-P03 no PC no	PMT Hamamatsu R7400-P03 yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 yes	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03 yes PC no	APD Licel APD3  yes  Analoq no  50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm	PMT Hamamatsu R7400-P04 no PC	PMT Hamamatsu R7400-P03 yes PC no	0.00 PMT Hamamatsu R7400-P03 no	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no	1.7 (variable) PMT Hamamatsu R7400-P03 yes PC no		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Neutral density filter Neut	0.80 APD Licel APD3 Yes Analog no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV	PMT Hamamatsu R7400-P04  no Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV 250 MHz	PMT Hamamatsu R7400-P03  yes  Analoq/PC no  50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV 250 MHz	PMT Hamamatsu R7400-P03 no PC no 50 Ohm	PMT Hamamatsu R7400-P03 no PC no 50 Ohm	PMT Hamamatsu R7400-P03 Yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 ohw	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 yes PC no	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  yes PC no  50 Ohm	APD Licel APD3  yes  Analoq no  50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV	PMT Hamamatsu R7400-P04 no PC no 50 Ohm	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm	0.00 PMT Hamamatsu R7400-P03 no PC no	0.6 (variable) PMT Hamamatsu R740-P03 no PC no S0 Ohm	1.7 (variable) PMT Hamamatsu R7400-P03 yes PC no 50 Ohm		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio	0.80 APD Licel APD3 yes Analog no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV	PMT Hamamatsu R7400-P04 no Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mW 250 MHz LICEL	PMT Hamamatsu R7400-P03  yes  Analoq/PC no  50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV 250 MHz LICEL	PMT Hamamatsu R7400-P03 no PC no 50 Ohm	PMT Hamamatsu R7400-P03 no PC no 50 Ohm	PMT Hamamatsu R7400-P03  yes  Analoq no  50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV  LICEL	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Ves PC no 50 Ohm	APD Licel APD3  yes  Analoq no  50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL	PMT Hamamatsu R7400-P04 no PC no 50 Ohm	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm	0.00 PMT Hamamatsu R7400-P03 no PC no 50 Ohm	0.5 (variable) PMT Hamamatsu R7400-P03  PC no  50 Ohm	1.7 (variable) PMT Hamamatsu R7400-P03 yes PC no 50 Ohm		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Neutral density filter OD Detector manufacturer Detector model Additional features Daytims capability Daytims capability Data capability Data capability Transimpedance Ampiller Transimpedance Ampiller Transimpedance Bandwidth Output impedance Analog sampling rate A-D bits Input termination Max input Voltage Photon counting count-rate Photon counting count-rate Data acquisition model Data acquisition model	0.80 APD Licel APD3 yes Analog no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no   Analoq/PC no   50 Ohm   40 MS/s   30 MHz   12 bit   50 Ohm   50 Ohm   LICEL TR20-160   7.5 m	PMT Hamamatsu R7400-P03 yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV 250 MHz LICEL TR20-160 7.5 m	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	>0.95 -(0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Ves PC no 50 Ohm  250 MHz LICEL TR20-160P 7.5 m	APD Licel APD3  yes  Analoq no  50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL TR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.00 PMT Hamamatsu R7400-P03 n0 PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.6 (variable) PMT Hamamatsu R7400-P03 P0 PC no PC No S0 Ohm 250 MHz LICEL LICEL LICEL LICEL LICED LIC	1.7 (variable) PMT Hamamatsu R7400-P03 yes PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio	0.80 APD Licel APD3  Ves  Analog no  50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 Ohm LICEL	PMT Hamamatsu R7400-P04 no   Analog/PC no   50 Ohm 40 MS/s   30 MHz   12 bit   50 Ohm   500 mV   250 MHz   LICEL   TR20-160   7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 500 ohm 500 mV 250 MHz LICEL TR20-160 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL ITR20-160P 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL LICEL TR20-160P 7.5 m	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Yes PC no 50 Ohm  250 MHz LICEL LICEL LICEL LICEL TR20-160P 7.5 m 10 s	APD Licel APD3  yes  Analoq no  50 Ohm 40 M5/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL LTR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	0.00 PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL LIC	1.7 (variable) PMT Hamamatsu R7400-P03  yes  PC no  50 Ohm  250 MHz LICEL LICE		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio	0.80 APD Licel APD3 yes Analog no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no   Analoq/PC no   50 Ohm   40 MS/s   30 MHz   12 bit   50 Ohm   50 Ohm   LICEL TR20-160   7.5 m	PMT Hamamatsu R7400-P03 yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV 250 MHz LICEL TR20-160 7.5 m	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	>0.95 -(0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Ves PC no 50 Ohm  250 MHz LICEL TR20-160P 7.5 m	APD Licel APD3  yes  Analoq no  50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL TR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.00 PMT Hamamatsu R7400-P03 n0 PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.6 (variable) PMT Hamamatsu R7400-P03 P0 PC no PC No S0 Ohm 250 MHz LICEL LICEL LICEL LICEL LICED LIC	1.7 (variable) PMT Hamamatsu R7400-P03 yes PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral Gensty filter OD Ventral Gensty filter Ventral Gensty filte	0.80 APD APD Litel APD3 Yes Analog no 50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 mV LIT20-150A T.5 in 660 km no	PMT Hamamatsu R7400-P04 no   Analog/PC no   50 Ohm 40 MS/s   30 MHz   12 bit   50 Ohm   500 mV   250 MHz   LICEL   TR20-160   7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 500 ohm 500 mV 250 MHz LICEL TR20-160 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL ITR20-160P 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL LICEL TR20-160P 7.5 m	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Yes PC no 50 Ohm  250 MHz LICEL LICEL LICEL LICEL TR20-160P 7.5 m 10 s	APD Licel APD3  yes  Analoq no  50 Ohm 40 M5/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL LTR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	0.00 PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL LIC	1.7 (variable) PMT Hamamatsu R7400-P03  yes  PC no  50 Ohm  250 MHz LICEL LICE		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio	0.80 APD Licel APD3  Ves  Analog no  50 Ohm 40 MS/s 30 MHz 12 bit 50 Ohm 500 Ohm LICEL	PMT Hamamatsu R7400-P04 no   Analog/PC no   50 Ohm 40 MS/s   30 MHz   12 bit   50 Ohm   500 mV   250 MHz   LICEL   TR20-160   7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 500 ohm 500 mV 250 MHz LICEL TR20-160 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL ITR20-160P 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL LICEL TR20-160P 7.5 m	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Yes PC no 50 Ohm  250 MHz LICEL LICEL LICEL LICEL TR20-160P 7.5 m 10 s	APD Licel APD3  yes  Analoq no  50 Ohm 40 M5/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL LTR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	0.00 PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL LIC	1.7 (variable) PMT Hamamatsu R7400-P03  yes  PC no  50 Ohm  250 MHz LICEL LICE		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Neutral density filter OD Detector manufacturer Detector model Additional reatures Daytime capability Data Acciliation Transimpedance Ampiller Transimpedance Ampiller Transimpedance Bandwidth Output impedance Analog sampling rate Input termination Max input Voltage Data acciliation Max input Voltage Data acquisition manufacturer Data acquisition manufacturer Raw data dange resolution Raw data time previous professional preventing of the Control of th	0.80 APD Licel APD3 Yes Analog no 50 Ohm 40 MS/s 30 MHz 50 Ohm 50 Ohm 50 Ohm 60	PMT Hamamatsu R7400-P04 no	PMT Hamamatsu R7400-P03 Yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 500 ohm 500 mV 250 MHz LICEL TR20-160 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL ITR20-160P 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL LICEL TR20-160P 7.5 m	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Yes PC no 50 Ohm  250 MHz LICEL LICEL LICEL LICEL TR20-160P 7.5 m 10 s	APD Licel APD3  yes  Analoq no  50 Ohm 40 M5/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL LTR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	0.00 PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL LIC	1.7 (variable) PMT Hamamatsu R7400-P03  yes  PC no  50 Ohm  250 MHz LICEL LICE		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Neutral density filter OD Detector manufacturer Detector manufacturer Detector manufacturer Detector model Additional features Daytime capability Data Accidition Data Accidition Data Accidition Data Accidition Transimpedance Ampilier Transimpedance Bandwidth Output Impedance Analog sampling rate Bandwidth Input termination Max input Voltage Data acquisition manufacturer Data acquisition manu	0.80 APD Licel APD3 yes Analog no 50 Ohm 40 MS/s 30 MHz 12 bit 13 bit 16 Git 10 Soon mV	PMT Hamamatsu R7400-P04 no	PMT Hamamatsu R7400-P03 Yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 500 ohm 500 mV 250 MHz LICEL TR20-160 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL ITR20-160P 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL LICEL TR20-160P 7.5 m	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Yes PC no 50 Ohm  250 MHz LICEL LICEL LICEL LICEL TR20-160P 7.5 m 10 s	APD Licel APD3  yes  Analoq no  50 Ohm 40 M5/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL LTR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	0.00 PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL LIC	1.7 (variable) PMT Hamamatsu R7400-P03  yes  PC no  50 Ohm  250 MHz LICEL LICE		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio	0.80 APD Licel APD3 VELCEL Incel INC	PATT Hamamatsu R7400-P04 no   Analog/PC no   Analog	PMT Hamamatsu R7400-P03 Yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 500 ohm 500 mV 250 MHz LICEL TR20-160 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL ITR20-160P 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL LICEL TR20-160P 7.5 m	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Yes PC no 50 Ohm  250 MHz LICEL LICEL LICEL LICEL TR20-160P 7.5 m 10 s	APD Licel APD3  yes  Analoq no  50 Ohm 40 M5/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL LTR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	0.00 PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL LIC	1.7 (variable) PMT Hamamatsu R7400-P03  yes  PC no  50 Ohm  250 MHz LICEL LICE		
Pol. Transmission parallel Pol. Transmission cross Contrast ratio Neutral density filter OD Detector manufacturer Detector manufacturer Detector model Additional reatures Daytime capability Data Acculiation Data Acculiation Transimpedance Ampiller Transimpedance Ampiller Transimpedance Bandwidth Output impedance Analog sampling rate A-D bits Input termination Max input Voltage Photon counting count-rate Data acquisition meanufacturer Raw data dange resolution Raw data time data time resolution Raw data data general time Scanning range Elevation Scanning range Azimuth Unattended operation Automated functions Daytime Counter of the Counter	0.80 APD Licel APD3 APD4 Licel APD3 Analog no SO Ohm 40 MS/s 30 MHz SO Ohm 50 Ohm 50 Ohm 60 O	PMT Hamanatsu R7400-P04	PMT Hamamatsu R7400-P03 Yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 500 ohm 500 mV 250 MHz LICEL TR20-160 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL ITR20-160P 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL LICEL TR20-160P 7.5 m	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Yes PC no 50 Ohm  250 MHz LICEL LICEL LICEL LICEL TR20-160P 7.5 m 10 s	APD Licel APD3  yes  Analoq no  50 Ohm 40 M5/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL LTR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	0.00 PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL LIC	1.7 (variable) PMT Hamamatsu R7400-P03  yes  PC no  50 Ohm  250 MHz LICEL LICE		
Pol. Transmission parallel Pol. Transmission parallel Pol. Transmission cross Contrast ratio of the Pol. Transmission cross Contrast ratio of the Pol. Transmission of the Pol. Pol. Pol. Pol. Pol. Pol. Pol. Pol.	0.80 APD Licel APD3 APD4 Licel APD3 Analog no 50 Ohm 40 NS/s 30 Mts 50 Ohm 500 mV LICEL TR20-160A T.5 m in [date; ves] Overlap scan CIMEL/AEONET be bit Wood Sca	PMT Hamanatsu R7400-P04	PMT Hamamatsu R7400-P03 Yes Analoq/PC no 50 Ohm 40 MS/s 30 MHz 12 bit 500 ohm 500 mV 250 MHz LICEL TR20-160 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL ITR20-160P 7.5 m 10 s	PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes Analoq no 50 Ohm 40 MS/s 20 MHz 12 bit 50 Ohm 500 mV LICEL TR20-160A 7.5 m	>0.95 <0.01 1.00E-03 1.0 (variable) PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL LICEL TR20-160P 7.5 m	>0.99  1.0 (variable) PMT Hamamatsu R7400-P03  Yes PC no 50 Ohm  250 MHz LICEL LICEL LICEL LICEL TR20-160P 7.5 m 10 s	APD Licel APD3  yes  Analoq no  50 Ohm 40 M5/s 30 MHz 12 bit 50 Ohm 500 mV  LICEL LTR20-160A 7.5 m	PMT Hamamatsu R7400-P04 no PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	PMT Hamamatsu R7400-P03 Yes PC no 50 Ohm 250 MHz LICEL LICEL TR20-160P 7.5 m	0.00 PMT Hamamatsu R7400-P03 no PC no 50 Ohm 250 MHz LICEL TR20-160P 7.5 m	0.6 (variable) PMT Hamamatsu R7400-P03 no PC no S0 Ohm 250 MHz LICEL LIC	1.7 (variable) PMT Hamamatsu R7400-P03  yes  PC no  50 Ohm  250 MHz LICEL LICE		

- Unattended Operation, e.g.
  - Automatic configuration (signal dynamic range)
  - Monitor signals and dynamically make adjustments.
  - Eye-safety/aircraft protection
- Unattended remote operation
  - Remote access to the system and all subsystems

It may not be possible or even necessary to jump from a manually operated lidar to a fully remotely controllable system. Rather than this, proper automation of a critical subsystem, such as adjustment of overlap between reveiving telescope and laserbeam, may be an effective way to improve data reliability. By subsequently automating parts of the lidar (automation will require funds to purchase hardware and manpower to build software) a better integrated and automated system will be come available.

### **ACKNOWLEDGEMENT**

EARLINET-ASOS is funded by the European Commission under grant RICA-025991.

### 11. REFERENCES

- [1] Diner, D. J., et al. (2004), PARAGON: An Integrated Approach for Characterizing Aerosol Climate Impacts and Environmental Interactions, Bulletin of the American Meteorological Society, 85(10), 1491-1501.
- [2] Freudenthaler, V., The Telecover Test: A quality assurance tool for the optical part of a lidar system, Proceedings ILRC24, Boulder, Colorado, June 22-27, 2008.
- [3] R. Agishev et al: "Lidarperformance prediction by dimensionless SNR-parameterization", Proc. of SPIE Vol. 5979 59791G-1 G-10, doi 10.1117/12.627569
- [4] Müller, D., et al. (1999), Microphysical particle parameters from extinction and backscatter lidar data by inversion with regularisation: theory, Applied Optics, 38(12), 2346-2357.