

Rapid CVD growth of millimetre-sized single-crystal graphene using a cold-wall reactor

Vaidotas Mišeikis¹


D. Convertino^{1,2}, N. Mishra¹, M. Gemmi¹, T. Mashoff¹, S. Heun³, N. Haghighian⁴,
F. Bisio⁵, M. Canepa⁴, V. Piazza¹ and C. Coletti^{1,2}

1. **Center for Nanotechnology Innovation @NEST, Istituto Italiano di Tecnologia, Pisa, Italy**
2. Graphene Labs, Istituto Italiano di Tecnologia, Genova, Italy
3. NEST, Istituto Nanoscienze—CNR and Scuola Normale Superiore, Pisa, Italy
4. Dipartimento di Fisica, Università di Genova, Genova, Italy
5. CNR-SPIN, Genova, Italy


Large-scale applications of CVD graphene

Innovations for industry adoption:


- Roll-to-roll processing allows high throughput
- CMOS integration: growth of graphene on 30-inch wafers
- Etchant-free electrochemical transfer allows re-using the substrate



Bae, S. *et al.* *Nat. Nanotechnol.* **5**, 1–5 (2010).




Rahimi, S. *et al.*
ACS Nano **8**, 10471–9 (2014).




Wang, Y. *et al.*
ACS Nano **5**, 9927–33 (2011).


Large-crystal CVD graphene: avoiding grain boundaries




Petrone *et al.*
Nano Lett. **12**, 2751–6 (2012).



Hao *et al.*
Science **342**, 720–3 (2013)



Zhou *et al.*
Nat. Commun. **4**, 2096 (2013)



Gan, L. & Luo, Z
ACS Nano **7**, 9480–8 (2013)

- Electrical properties can be comparable to exfoliated flakes.
- Single crystals can be as large as several mm (even cm).

BUT, the use of single-crystal CVD graphene in applications still not very common. Why?

- Large-crystal growth not trivial to implement due to high variability between different systems.
- Very long growth times required for mm-sized crystals.

Our CVD system: Aixtron BM Pro

- Cold-wall reactor
- 4-inch heating stage
- Bottom + top heater

Standard growth procedure:

25 mbar



Copper annealing in hydrogen

1060 °C bottom + 950 °C top

1 sccm CH₄ + 980 sccm Ar + 20 sccm H₂ (optional?)

Continuous film grown in 5 minutes


Good-quality and highly repeatable growth, but polycrystalline, with grain size limited to ~10 μm.



Reducing the nucleation density


Hydrogen annealing

- High nucleation density ($\sim 10\,000$ per mm^2)
- Growth along the copper foil rolling grooves
- Compact edges



Argon annealing




- Reduced nucleation density ($\sim 1\,000$ per mm^2)
- Growth distributed more randomly
- Dendritic edges characteristic of oxygen-assisted growth (Hao *et al. Science* **342**, 720–3 (2013))
- Large (up to several mm) Cu crystal domains



Argon annealing inside an enclosure


- Significantly reduced nucleation density ($\sim 5\text{--}10$ per mm^2)

V. Miseikis *et al. 2D Materials* **2**, 014006 (2015)



Sample enclosure


- 6 mm-thick graphite spacers placed directly on the bottom heater
- Sample and the spacers covered with a quartz disk
- Limits gas flux and creates more equilibrium conditions (10 cm³ vs 21 litres)
- Reduces the deposition of evaporated copper in the main chamber



Reducing the nucleation density


Hydrogen annealing

- High nucleation density ($\sim 10\,000$ per mm^2)
- Growth along the copper foil rolling grooves
- Compact edges




Argon annealing

- Reduced nucleation density ($\sim 1\,000$ per mm^2)
- Growth distributed more randomly
- Dendritic edges characteristic of oxygen-assisted growth (Hao *et al. Science* **342**, 720–3 (2013))
- Large (up to several mm) Cu crystal domains




Argon annealing inside an enclosure

- Significantly reduced nucleation density (~ 5 -10 per mm^2)




V. Miseikis *et al. 2D Materials* **2**, 014006 (2015)

The effect of oxygen content in copper




→
Growth with Ar
annealing




Low purity foil (99.8%) / high oxygen content

↓
Growth with Ar
annealing





High purity foil (99.98%) / low oxygen content

→
2 min @ 180 °C
Growth with Ar
annealing






Thermally oxidised high purity foil

Flat foil: graphene crystals approaching 1 mm



- Growth rate linear $\sim 15 \mu\text{m}/\text{min}$
- Up to $750 \mu\text{m}$ crystals grown before they start merging


Growth using copper “pocket”



- Nucleation significantly lower than 1 crystal per mm²
- Growth of up to 3.5 mm single-crystals in 3 hours
- PMMA transfer can be challenging due to foil deformation

V. Miseikis *et al.* 2D Materials 2, 014006 (2015)



Rotationally aligned growth



- Separate graphene crystals formed on a single Cu crystal domain have the same orientation.
- Visible with SEM, confirmed with LEED.




Raman spectroscopy

- No D-peak indicates high crystal quality
- $I(2D) / I(G) \sim 3$
- $\text{FWHM}(2D) \sim 29 \text{ cm}^{-1}$
- Homogeneous Raman signature over the whole transferred crystal



Conclusions

- Key factors for the growth of mm-scale graphene single crystals
 - Cu substrate chemistry (primarily, oxygen content)
 - annealing conditions (argon instead of hydrogen)
 - use of enclosure (external enclosure and/or copper “pocket”)
- High quality of synthesised graphene
- The growth is fast, allows routine production of mm-scale graphene crystals for applications.



Acknowledgements

Laboratorio NEST, Pisa, Italy

Stefano Roddaro, Francesco Rossella

Aixtron LTD, Cambridge, UK

Ken Teo, Nalin Rupesinghe, Paul Greenwood

Thank you for your attention!

Further information:

V. Miseikis *et al.* 2D Materials 2, 014006 (2015)